



<p>1.</p> <p>#12-24 mounting screws</p> <p>Attach screws to rear of panel.</p>	<p>2.</p> <p>Mount strain relief bar.</p>
<p>3.</p>	<p>4.</p> <p>Use Tak-Ty Hook & Loop Cable ties for cable management.</p>