

# Datamate Tooling

❖ Instruction sheets (where available) can be accessed at [www.harwin.com/Downloads/Instructions](http://www.harwin.com/Downloads/Instructions)

## SEPARATOR TOOL

- ❖ Recommended for unplugging L-TEK latched connectors (tool releases the latches prior to disengagement).
- ❖ Can also be used with unlatched and friction lock connectors.
- ❖ Suitable for all sizes.



### ORDER CODE

L-TEK	<b>T5746</b>
-------	--------------

## INSERTION/REMOVAL TOOL

- ❖ For inserting crimped contacts into the rear of mouldings.
- ❖ Instruction sheet available.
- ❖ Suitable for all Datamate signal contacts.



### ORDER CODE

Signal crimps for L-TEK, J-TEK & MIX-TEK	<b>Z80-280</b>
--	----------------

## HAND CRIMP TOOL

- ❖ Standard coax crimp tool for crimping the outer sleeve of MIX-TECH coax contacts.
- ❖ Instruction sheet available.




### ORDER CODE

Outer sleeve of MIX-TEK coax contacts	<b>Z80-293</b>
---------------------------------------	----------------

## REMOVAL TOOL

- ❖ To aid removal of special cable contacts from MIX-TEK connectors.



### ORDER CODE

MIX-TEK special cable connectors	<b>Z80-290</b>
----------------------------------	----------------

[www.harwin.com](http://www.harwin.com)